

Automatic Battery Charger Selection Chart

Type	Version	Power Input (VAC 50/60 Hz)		Charge Volt. VDC		Output Current DC (A)	Charge Mode
				Battery Volt. (V)	Output Volt. (V)		
CH3512	Panel Mount	110 / 220	Auto	12	13.8	5	Float charge
CH3524		110 / 220	Auto	24	27.6	3	Float charge
CH1012	Portable	110	Fix	12	13.8	4	Float charge
CH2012		220	Fix	12	13.8	4	Float charge
CH1024	Portable	110	Fix	24	27.6	4	Float charge
CH2024		220	Fix	24	27.6	4	Float charge
CH1112	Portable	110	Fix	12	13.8	10	Float charge
CH2112		220	Fix	12	13.8	10	Float charge
CH1124	Portable	110	Fix	24	27.6	10	Float charge
CH2124		220	Fix	24	27.6	10	Float charge
CH1212	Portable	110	Fix	12	13.8	15	Float charge
CH2212		220	Fix	12	13.8	15	Float charge
CH1224	Portable	110	Fix	24	27.6	15	Float charge
CH2224		220	Fix	24	27.6	15	Float charge
CH1712	Wall Mount	110 / 220	Adjustable	12	13.8	20	Float / Equalized
CH1724		110 / 220	Adjustable	24	27.6	20	Float / Equalized
CH1812	Portable	110 / 220	Adjustable	12	13.8	20	Float / Equalized
CH1824		110 / 220	Adjustable	24	27.6	20	Float / Equalized

