

Automatic Battery Charger Selection Chart

Model No.	Installation Type	Power Input		Charge Volt. VDC		Output Current DC	Charge Mode
		(VAC 50/60 Hz)		Battery Volt. (V)	Output Volt. (V)	(A)	
CH4612	Panel Mount	110 / 220	Auto	12	13.8	5	Float charge
CH4624		110 / 220	Auto	24	27.6	3	Float charge
CH5612	Panel Mount	110 / 220	Auto	12	13.8	12	Float charge
CH5624		110 / 220	Auto	24	27.6	6	Float charge
CH1124	Portable	110	Fix	24	27.6	10	Float charge
CH2124		220	Fix	24	27.6	10	Float charge
CH1712	Wall Mount	110 / 220	Adjustable	12	13.8	20	Float / Equalized
CH1724		110 / 220	Adjustable	24	27.6	20	Float / Equalized
CH1812	Floor Standing	110 / 220	Adjustable	12	13.8	20	Float / Equalized
CH1824		110 / 220	Adjustable	24	27.6	20	Float / Equalized



TEL: +886-7-8121771 FAX: +886-7-8121775
 Headquarters: No.3, Lane 201, Chien Fu St., Chyan Jenn Dist., Kaohsiung 806037, TAIWAN
 Please link to <http://www.kutai.com.tw> for detailed manual.